

ClearOne® **Aura**™

Quick-Start Guide



VERSA™ 50
COMPLETE SOLUTION

CONTACT INFORMATION

Headquarters

5225 Wiley Post Way
Suite 500
Salt Lake City, UT 84116
US: +1.801.975.7200
International: +1.801.975.7200

Aura Sales

US: +1.888.HEY.AURA
International: +1.801.975.7200
aurasales@clearone.com

Aura Tech Support

US: +1.888.HEY.AURA
International: +1.801.975.7200
auratechsupport@clearone.com

NOTICES

© 2021 ClearOne, Inc. All rights reserved.

Information in this document is subject to change without notice.

Document: QSG-0075-002v1.1, February 2021

COMPONENTS INCLUDED

The Versa 50 includes the UNITE® 50 4K ePTZ Camera, CHAT® 150 USB speakerphone, Versa Hub, and a free COLLABORATE® Space lifetime subscription.

Versa 50	
	<p>AUR-2100-006</p> <p>UNITE 50 4K ePTZ camera, USB cable, and camera remote control</p>
	<p>AUR-3001-100</p> <p>Versa Hub, USB 3.0 input cable, power supply, DVI - VGA adapter</p>
	<p>AUR-156-200</p> <p>CHAT 150 Speakerphone with USB cable</p>
	<p>Free COLLABORATE Space lifetime subscription</p>

Versa™ 50

SET UP YOUR PRODUCT


1. Connect the UNITE 50 to the USB 3.0 port on the Versa Hub.



2. Connect the CHAT 150 speakerphone to the USB 2.0 port on the Versa Hub.



3. Connect up to two room displays to the DVI and HDMI output port on the Versa Hub.



4. Connect the Versa Hub to the power supply. Connect the Versa Hub to the network (optional) if the laptop needs network connectivity.



Versa™ 50

5. To cast a laptop screen onto a display via USB 3.0, install the DisplayLink driver (one time installation) onto the laptop. You can download the driver from:

www.displaylink.com/downloads

Note: If a Windows 10 laptop comes with the DisplayLink driver pre-installed, it does not need to be installed separately. The Versa Hub has been tested with DisplayLink driver version 8.2.1999.0.

6. Connect your laptop to the USB 3.0 input port on the Versa Hub.



For detailed information regarding the CHAT 150 or UNITE 50 products, please refer to the appropriate user manual or quick start guide on the ClearOne website:

www.clearone.com